

## No More Gaps Timber Flooring

### Description

No More Gaps® Flexible Timber Flooring Gap Filler is specially designed for filling and sealing gaps around and between tongue and groove timber flooring and also between other timber panels and fittings where extra flex is required.

It is formulated to provide superior, long lasting resistance to the movement of hardwood timber floorboards and other timber panels and fittings, created by temperature and humidity changes. It is available in four timber colours to match a wide range of timber types.

### Product Information

No More Gaps Timber Flooring is made in different colours to match the appearance of different timbers.

Packaging	Size	Colour	Timbers
Cartridge	380 g	Jarrah	Jarrah, River Red Gum and Karri.
Cartridge	380 g	Hardwood	Black Butt, Spotted Gum, Brush Box, Tasmanian Oak, Cypress and Beech.
Cartridge	380 g	Walnut	Ironbark, Teak, Dark stained timbers, engineered floors.
Cartridge	380 g	Baltic	Pine, Myrtle, Alpine Ash.

### Uses

No More Gaps Flexible Timber Flooring Gap filler is used for filling and sealing gaps in hardwood timber floors and around and between all types of timber panels and fittings. Also for use in bedroom and kitchen fittings, benchtops, skirting boards and architraves.

### Features

- Flexible gap filler
- Sandable
- Stainable
- Contains real wood fibre

### Technical Details

Property	Typical Result
Technology	Water-based
Density	1.30-1.35
Skin Time	30 minutes

Peel Strength Anodised Aluminium)	+110 N
Shore A Hardness	50
Elongation at Break (ASTM D412)	+500%
Modulus at 100% Elongation (ASTM D412)	0.3
Movement Capability (ISO 9046)	25%
Indicative data only, not intended for preparation of specifications	

### Directions for Use

1. Surface to be filled must be clean, dry and free from dust.
2. Cut seal and nozzle to suit width of gap. Fit to cartridge. Insert into caulking gun.
3. Apply with caulking gun, forcing product into the gap.
4. Press in and smooth off with a spatula. Take care not to drag out applied filler from the gap. Use spatula to scrape off as much residue as possible from the timber surface to minimise sanding necessary.
5. Clean up with a damp cloth immediately.
6. Allow to dry for at least 24 hours before sanding off any residue from timber surface. Allow longer time in colder weather or if residue left on timber is excessive.
7. Stain and varnish/paint as desired. Ensure stain/varnish is not allowed to pool in the joint – lightly wipe off while wet if necessary.

### Tips

Ensure sufficient product is applied into gap, if filling tongue and groove overlaps.

Re-apply filler if timber movement is excessive and movement capability is exceeded, or if a flush fill is desired.

### Coverage

Covers 18 metres with a 3 mm bead.

# No More Gaps Timber Flooring

---

## Storage

Store above 5 °C.

## Limitations

- Not for gaps >3mm wide in trafficable joints.
- Not for exterior use.

## Warnings, First Aid and Shipping Information

This information can be located on the product SDS found through our website – [www.selleys.com](http://www.selleys.com)